SAQ-501 SCHEMATIC DIAGRAM



S1 SELECTOR (S1A~S1D)			
* 1	2	3	4
T.H	PHONO	TUNER	AUX

* POSITION ON DIAGRAM

S2 MODE (S2A, S2B)				
1 *	2	3	4	5
LEFT	RIGHT	MONO	STEREO	REVERSE

* POSITION ON DIAGRAM